









HU0-11~16 配 RHU-10/□1 外形尺寸：




HUO-18/23/HUO-32R配RHU-10/□1外形尺寸



HUO-18/23/HUO-32R配RHU-80/□1外形尺寸：






HUO-27~38配RHU-10/□2 外形尺寸：
 (0.1A~30A負載側不加接板，僅36A及38A機種負載側加接板)






固定尺寸

HUO-27~38配RHU-80/□4 外形尺寸



HUO-40配RHU-80/□2 外形尺寸：



HUO-50~ 90配RHU-80/□3 外形尺寸

